



Rush+ spectacles blue-black clear

Modern safety glasses with ultra-sporty design and PLATINUM-coated clear lenses for work use. Provides also added upper protection. Adjustable non-slip nose bridge. Highly flexible co-injected two-colour temples with thin structure.

High-quality optics, light weight and modern design provide comfort, and the curved top of the lens also provide additional protection from above. The molded temples are flexible and fit well. Non-slip coating on the temple arms provide a firm grip and stability for the glasses, even in difficult working positions and active movement. Soft and adjustable nose pads.

Protects eyes from UV rays without affecting color resolution and low-energy mechanical hazards (6 mm 0.86 g metal ball at 45 m / s), even at extreme temperatures. Anti-fog coated Class-N, and anti-scratch coated Class-K lenses. Polycarbonate lens optics class 1: Designed for long-term continuous use.

PLATINUM-coating benefits:

- High resistance to fogging to offer excellent visibility in changing conditions
- High resistance to mechanical abrasion and scratches (1.4 cd/m²)
- Permanently on both sides of lenses
- Wash resistant (cleaning with water & soap -combination or Bollé Safety B-Clean maintenance products)
- Improves work efficiency, safety, reliability and user experience
- Recommended choice for versatile universal use as well as for hot and humid conditions and sweat-raising tasks

Frame Marking: EN166 FT CE

Lens Marking: 2C-1.2 1 FT KN CE

Bollé Safety, founded 1888, is a leading global brand in the PPE eyewear market. Bollé Safety develops products and technologies to protect workers' vision across all activities:

- Industrial
- Tactical & first responders
- Blue Light
- Prescription
- Cleanroom
- Healthcare

CSP lens technology – Comfort, Sense, Perception

COMFORT.

Visual comfort is all about contrast optimisation and colour enhancement. Regardless of sunlight and glare, you want to keep enjoying precise details and colour accuracy. With CSP, our lens tints are adapted to unique work environments, ushering in a new era of exceptional visual

RUSHPPSIB

3 660740 007171