



Cobra spectacles HD

Supreme safety glasses with a very wide 180-degree panoramic view and HD lenses for work use. Designed for indoor use by healthcare professionals (dentists, oral hygienists, nurses, surgeons, doctors, etc.), electrical and electronics installations, industry, sticker installations, painting quality control and other professions where very high accuracy and resolution are required. The best glasses available on the market for vaccinations. Not recommended for conditions where protection from sunlight or blue light is required.

Protects eyes from UV rays without affecting color resolution and low-energy mechanical hazards (6 mm 0.86 g metal ball at 45 m / s), even at extreme temperatures. The cap edge at the top also provides protection from splashes from above. Polycarbonate lens optics class 1: Designed for long-term continuous use.

The angle of the lens can be vertically adjusted with the temple arm hinges, to perfectly fit any head. Non-slip nasal bridge and temple arms ensure excellent grip and stability. The temples are detachable, which allows the glasses to be converted into protective goggles using the KITFSCOB set.

Advantages of HD (High Definition) polymer coated lenses:

- Provides an exceptionally bright field of view and prevents reflections almost completely
- Light transmittance of 96%, the best transmittance on the market, which makes the glasses suitable for precision work (the transmittance of a regular clear safety lens is about 90%)
- Makes glasses very dirt and water repellent (= hydrophobic), suitable for even the wettest conditions and work tasks where splashes occur
- Reduces eye strain with prolonged use

Technical information:

Frame marking: EN166 FT CE

Bollé Safety, founded 1888, is a leading global brand in the PPE eyewear market. Bollé Safety develops products and technologies to protect workers' vision across all activities:

- Industrial
- Tactical & first responders
- Blue Light
- Prescription
- Cleanroom
- Healthcare

CSP lens technology – Comfort, Sense, Perception

COMFORT.

Visual comfort is all about contrast optimisation and colour enhancement. Regardless of sunlight and glare, you want to keep enjoying precise details and colour accuracy. With CSP, our lens tints are adapted to unique work environments, ushering in a new era of exceptional visual

COBHDPI

